

KitchenCraft

GRAIN	GRAIN AMOUNT	WATER	TIME	RESTING TIME
	(DRIED)	(CUPS)	(MINUTES)	(MINUTES)
Couscous	1/4 cup	1/4 cup	2	0
Couscous	1/2 cup	1/2 cup	2	0
Couscous	3/4 cup	3/4 cup	2	0
Couscous	1 cup	1 cup	2	0
Quinoa	1/4 cup	1 cup	10	1
Quinoa	1/2 cup	1 1/2 cups	11	1
Quinoa	3/4 cup	1 3/4 cups	12	1
Quinoa	1 cup	2 cups	13	1
Long grain rice	1/4 cup	1 cup	10	3
Long grain rice	1/2 cup	1 1/4 cups	10	3
Long grain rice	3/4 cup	1 1/2 cups	11	3
Long grain rice	1 cup	2 cups	11	3
Long grain rice	2 cups	4 1/2 cups	14	3
Long grain rice	3 cups	5 cups	16	3
Orzo whole wheat pasta	1/4 cup	1 cup	12	0
Short grain rice	1/2 cup	1 cup	12	0
Short grain rice	3/4 cup	2 cups	13	0
Minute white rice (whole grain)	1 cup	1 cup	6	0

KitchenCraft®
a LifetimeBrands company

IS A REGISTERED TRADEMARK OWNED BY THOMAS PLANT (BIRMINGHAM) LTD,
PLUMBOB HOUSE, VALEPITS ROAD, GARRETT'S GREEN, BIRMINGHAM,
WEST MIDLANDS, B33 0TD, GB.
ESTABLISHED 1850 WWW.KITCHENCRAFT.CO.UK

All recipes are based on 800 watt microwaves. If your microwave is a different wattage adjust cooking times accordingly.
For all other foods consult your microwave cookbook.

For even browning remember to turn halfway through the cooking cycle.

KitchenCraft®

MICROWAVE RICE COOKER

UK

Take care when removing product from packaging. Wash thoroughly before first use. This product is dishwasher, microwave, fridge and freezer safe. Avoid use of metal utensils and scourers to prevent damage to the interior material. Item will become hot during microwave use. Always use oven gloves when handling this product from the microwave. Never use with a grill or a convection function in a microwave. Do not use on a hob or in a conventional oven.

Preparation ratios may be varied according to taste. Always stop cooking half way through and stir.

USING GUIDE:

1. Place all ingredients into the rice cooker
2. Place the required amount of water into the rice cooker in accordance with the cooking guide above.
3. Place the lid on top of the container and make sure that locking clips at each side are fastened.
4. Cook for the required time.

Please note that cooking times may vary depending on the power of your microwave oven.

Microwave at "high" power setting.

Allow cooked rice to "stand" for two minutes before serving.

WARNING - VERY HOT STEAM WILL ESCAPE WHEN OPENING THE COOKER.

CARE

- Do not overcook food or use this product without food.
- Never use this product with a grill or convection facility switched on.
- Suitable for microwave use only.
- Do not use in a traditional oven.
- Ensure food is piping hot throughout before serving
- Do not use sharp utensils or abrasive scouring materials, as they may damage the surface. Therefore simply wash with a dishcloth or place on the top rack of your dishwasher.
- Foods with high quantities of fat, oil or sugar may cause discolouring.
- Dishwasher safe
- Microwave oven safe to 120°C / 248°F.

F

Faire attention en retirant le produit de l'emballage. Bien laver avant la première utilisation. Ce produit peut être utilisé au réfrigérateur, congélateur, au four à micro-ondes et dans un lave-vaisselle. Il est recommandé de ne pas utiliser d'ustensiles en métal et de tampons à rincer pour éviter d'endommager le revêtement intérieur. L'article devient chaud lors de l'utilisation au micro-ondes. Toujours utiliser des gants de cuisine en sortant ce produit du micro-ondes. Ne jamais utiliser avec un gril ou une fonction de convection dans un micro-ondes. Ne pas utiliser sur un plan de cuisson ou dans un four conventionnel.

Les ratios de préparation peuvent être modifiés en fonction des goûts. Toujours arrêter à mi-cuisson et remuer.

GUIDE D'UTILISATION:

1. Placer tous les ingrédients dans le cuiseur à riz
2. Mettre la quantité d'eau requise dans le cuiseur à riz selon le guide d'utilisation ci-dessus.
3. Placer le couvercle sur le récipient et s'assurer que les clips de verrouillage de chaque côté sont bien attachés.
4. Faire cuire pendant la durée requise.

Veuillez noter que les temps de cuisson peuvent varier en fonction de la puissance de votre four à micro-ondes.

Régler le four à micro-ondes sur puissance "élévée".

Une fois le riz cuit, le laisser reposer pendant deux minutes avant de servir.

ATTENTION - DE LA VAPEUR TRÈS CHAUDE S'ÉCHAPPE LORS DE L'OUVERTURE DU CUISEUR.

ENTRETIEN

- Ne pas faire trop cuire les aliments ou utiliser ce produit sans aliments.
- Ne jamais utiliser ce produit avec un gril ou une unité à convection allumé(e).
- Convenable à l'utilisation au micro-ondes uniquement.
- Ne pas utiliser dans un four traditionnel.
- S'assurer que tous les aliments sont bien chauds avant de servir.
- Ne pas utiliser d'ustensiles tranchants ou de matériaux à rincer abrasifs au risque d'endommager la surface.
- Laver simplement avec un torchon ou placer dans le panier supérieur de votre lave-vaisselle.
- Les aliments contenant de grandes quantités de graisse, d'huile ou de sucre peuvent provoquer une décoloration.
- Article résistant au lave-vaisselle
- Article résistant au four à micro-ondes jusqu'à 120°C / 248°F.